

Last updated: 6/25/2024

Updated by: Max Schafer x3373 schaferm@grinnell.edu

DJI OSMO MOBILE SE (GIMBAL)

1. BEFORE USE

- Ensure the battery is well-charged – press the “M” button once and battery status should display on the screen
- Check the unit and all accessories for damage and cleanliness, and report to Max or Circulation Staff if anything is amiss

2. BASICS



- Insert your phone so that the extending arms of the grip are on the back. Center it horizontally and vertically on your phone. The image of a camera on one of the arms should point roughly to where your camera is
- Noting the alignment of magnets, attach the phone grip to the device
- Lifting the arm out of its locked position, press and hold the “M” button until it beeps and begins to stabilize itself
- Move slowly to maintain stability, and use the joystick to adjust the intended direction and angle

3. ADVANCED

- Download the DJI Mimo app (QR code inside the lid of the box)
- This allows the device to pair with your phone. You may now use the orange circle button, trigger, side zoom toggle, and two-arrow mode select circle button
- If your phone needs additional cushion to fit into the grip, apply the small black foam inserts located in the box

4. WHEN FINISHED

- Ensure device is turned off, and the arm returned to the locked position
- Bring item and all accessories to the Circulation Desk for checking in